

ASSEMBLY INSTRUCTION

4168-4405-4406

AX 1 	GX 5 
BX 2 	HX 4  8 X 16
CX 1 	IX 2  8 X 55
DX 1 	JX 2  8 X 50
EX 1 	KX 1 
FX 1 	

